

Super Skim Coat for thin wall rendering

M650



Instruction for Mortar preparation

- Mix 1 bag (20 kg) of TPI M650 with 8 liters of clean water until the mixture is homogeneous and without lumps of mortar.
- Use steel trowel to apply first layer coating of Super Skim Coat TPI M650 and which is almost dry then plaster to another layer with the same procedure until it is reached the required thickness (1-2 mm).
- In order to obtain smooth surface, use the fine sandpaper before painting the wall.

Technical Information

Package size	Thickness in Plastering (mm.)	Area of Plastering (sq.m.)	Amount of mortar per 1 sq.m. (kg)
20 kilograms	1-2	10	2

Suitable for Wall Rendering with Smooth, Fine and Beautiful surface.